




EN

AINA Connected

Quick Guide Version 1.1

THIS GUIDE HELPS
USERS TO QUICKLY
UNDERSTAND THE
SETUP AND USE OF THE
AINA CONNECTED
APPLICATION.



Visit www.aina-wireless.com to find additional solutions and more user guides. If you have any further questions, you can also email us at: sales@aina-wireless.com



HOW TO INSTALL

1

Download and install "AINA Connected" from the Google Play Store



2

Open the AINA Connected application from your phone's applications menu



3

AINA Connected will need access to the phone's location in order to find BLE devices. Accept the permission requests to complete the installation.



PAIRING

1

(i) Turn on your PTT Voice Responder by holding down the power button for 7 seconds and (ii) put it into pairing mode by pressing both arrow buttons and both PTT buttons simultaneously until the LED turns off momentarily, continued by constant green LED blinks

i



ii



*If you have a PTT Smart Button, put it into pairing mode by pressing all three buttons simultaneously


2

Press the plus icon



No devices! Click on the plus to add!

In the application, press the plus icon on the bottom right corner to pair an AINA device.



3

Select your device



Scanning for AINA devices!
Once the device you are trying to add appears on the list, click on it to start the bluetooth pairing process.
You can also use NFC to pair AINA RSM device, if NFC is available and enabled on your phone!

Devices found:
APTT300017



Wait for your device to appear on the list (friendly name is printed on the back of the Voice Responder) and then select it to start the pairing process.



4

Wait for the device to pair

08:49 100%

Connecting to APTT3000E7...



NOTE! A pairing request might appear on the screen. If this is the case, accept it to complete the pairing process.

5

Paired!

08:51 100%
AINA Connected

APTT3000E7
Battery level: 100%



ASB19745A
Battery level: 75%




Your device has successfully paired when the connection icon turns green.

DEVICE CONFIGURATION

1


Select your device



By selecting your device from the list, you can see the device name, firmware version and system configuration selected, and access the configuration settings.

2


Select "CONFIGURE"



Select "CONFIGURE" to change the system configuration and access additional information about your device.

3

Change the system/device configuration




Change the system configuration by opening the drop-down menu and selecting the correct configuration for your device.

ADDITIONAL FEATURES

1


Device details



Select your device from the list and then “CONFIGURE” to see its MAC address, firmware version, battery level etc.

2


Unpair / remove device



To unpair your device, press it for long in the menu and accept the unpairing request OR go the device details menu and press the “REMOVE DEVICE” button.

3

Additional settings



Select the three dots at the top right corner of the screen to access About, Settings and Stop service.

4

Connection icons



Disconnected



Re-connecting / connecting



Connected

TROUBLESHOOTING

1

The connection process is taking too long or the connection icon is not turning from yellow to green

If the connecting / reconnecting process seems to be taking a long time, we recommend pressing the AINA device's PTT button once. If the connection symbol still stays yellow, tap the device on the list which you are trying to connect.



2

The AINA device is not found

Make sure your device is on AINA mode, because the AINA Connected application only searches for devices that are in this mode and not JPTT or KPTT, for example.

3

The connection fails and you need to re-pair or re-connect the device

If you need to re-pair or re-connect the device, you first need to put your AINA device into pairing mode and remove the previous Bluetooth pairing from the phone.