

# QUICK GUIDE


## Connecting your PTT Voice Responder to WAVE 5000 (Android) (EN)



# A

## Pairing your PTT Voice Responder with your smartphone via Bluetooth

1. Turn on your PTT Voice Responder by holding down the Power button for more than 3 seconds. After it is on, a blinking green light will indicate that the device is ready for pairing.
2. Turn on your smartphone's Bluetooth by going to: Settings → Bluetooth → Turn on.
3. Pair your PTT Voice Responder to your smartphone by selecting it from the 'Available devices' list. To know which device to select from the list, check the unique friendly-name on the back of your Voice Responder. Once it has successfully paired, a blue light will begin blinking on your device.



**NOTE:** The Voice Responder can only be paired with one device at a time. If you want to pair it to another device you need to perform an **Unpairing/ Software reset** by pressing and holding both arrow buttons and both PTT buttons simultaneously, until the LED turns off.






# B

## Connecting your PTT Voice Responder to WAVE 5000

After having paired the Voice Responder on the OS level, follow these steps:

1. Select the three vertical dots displayed on the top right corner
2. Select “App Settings”
3. Turn on “Use Bluetooth Device for PTT”



If the app cannot find your PTT Voice Responder, make sure that your Voice Responder is still connected to your phone via Bluetooth (the LED should be blinking in blue). If it is not, perform part A again.

